

Field Mulling Instructions

1. Remove fin by scoring the fin on front and back and using pliers to "crank" the fin back and forth until it comes off.



2. After removing the fin, attach the mull strip to the edge of the unit on front and back side of the unit by hand (loose fit)



3. Use a 1 $\frac{1}{4}$ " machine screws to screw both units together under the sill (toe-nailed) and under the sash stop on both the left and right units facing eachother. It is best to do this on a flat surface.





4. When finished the sill should look like the below picture. Also pictured temporary shipping bracket that is typically removed before install at the jobsite.

