



Installation Manual

BIG MOUTH OUTLETS



BIG MOUTH OUTLETS



Hold the Big Mouth up to the gutter, and mark on the gutter where the hole in the Big Mouth is.



Then, using a tin snip, cut the gutter so the opening is the same as the opening in the Big Mouth.. Bend tabs down and cut to 3/4 inches long.



Screw in the Big Mouth and attach corners. Don't over tighten.



Tack the bottom elbow into place, so you can measure how long of a downspout you will need. Measure from the top of the bottom elbow to the bottom of the corners. Add 3" to your exact measurement so you will be able to tuck it into the corners.





Cut the downspout to length (your measurement plus 3 inches)



Attach the pipe bands to the siding. Use gutter screws if it is wood siding, use zip screws if it is any other type of siding.



Fit the top corner into the downspout.



Bend the pipe band around the downspout and screw into place. Do not over tighten.

